

# Door Installation



**IMPORTANT:** This requires skill with a power drill.

In addition to your doors, components will include:

Tools Needed:



European Style Hinges  
(Qty. depends on door size)



Hinge Screws  
(2 of each per hinge)



Rubber Bumpers  
(2 per door)



Philips Head  
Screw Driver  
(Not Included)



Driver Drill  
(Not Included)

Attach Hinges to Door and Upright  
using a Driver Drill



Wood Screw

Use wood screws to attach hinge to wood upright



Dowel Screw

Use dowel screws to attach hinge to wood door

Attach Rubber Bumpers



Peel off rubber bumpers and place on the top and bottom corners of doors.

Adjusting Hinges

Use a screw driver. Do not use your drill.

Turn this screw  
to adjust door  
inward or outward

Turn this screw  
to adjust door  
up or down

Turn this screw  
to adjust door  
left or right



Questions? Call us Toll Free in US: (888) 989-1370

Monday - Friday, 8:30 - 5:00 Pacific Standard Time